

CGS641A

INSTRUCTOR

Dr. Pragathi Balasubramanian

TOPIC

SLEEP RELATED NEURAL DISORDER- SLEEP APNEA AND ITS RELATION
WITH DIFFERENT TYPES OF BRAIN WAVES

1.INTRODUCTION

Sleep apnea is a neurological disease which affects millions world wide.During my research I first discover the basic signs and the nature of sleep apnea and how is it different from other disabilities.

In the second half I will be looking at the more technical side of it including observation of its EEG data.

In the last section I will be concluding the research on how can we lower its effects on the affected.

1.1 Sleep Apnea

Sleep apnea is a potentially serious sleep disorder in which breathing repeatedly stops and starts. If you snore loudly and feel tired even after a full night's sleep, you might have sleep apnea.

Sleep apnea happens when upper airway muscles relax during sleep and pinch off the airway, which prevents you from getting enough air. Your breathing may pause for 10 seconds or more at a time, until your reflexes kick in and you start breathing again

There are two types of sleep apnea-OSA and CSA

Obstructive sleep apnea happens when air can't flow into or out of the nose or mouth, although you're trying to breathe.

Central sleep apnea happens when the brain fails to send the right signals to your muscles to make you start breathing. (This type is less common.)

We will be relating OSA(obstructive sleep apnea) in this study because CSA is very uncommon in population.

Its scale-Sleep apnea occurs in about 3 percent of normal weight individuals but affects over 20 percent of obese people.

<https://www.hopkinsmedicine.org/health/wellness-and-prevention/the-dangers-of-uncontrolled-sleep-apnea#:~:text=There%20are%20two%20kinds%20of,apnea%20and%20central%20sleep%20apne>

So isn't Sleep apnea , just snoring?

Snoring is just the vibration sound created by airway resistance. You can snore loudly and not have sleep apnea, and you may even have sleep apnea without much snoring. The most common symptoms of obstructive and central sleep apneas include:

- Loud snoring.
- Episodes in which you stop breathing during sleep – which would be reported by another person.
- Gasping for air during sleep.
- Awakening with a dry mouth.
- Morning headache.
- Difficulty staying asleep, known as insomnia.
- Excessive daytime sleepiness, known as hypersomnia.
- Difficulty paying attention while awake.
- Irritability.

<https://www.mayoclinic.org/diseases-conditions/sleep-apnea/symptoms-causes/syc-20377631#:~:text=Sleep%20apnea%20is%20a%20potentially,you%20might%20have%20sleep%20apnea.>

STOP		
Do you SNORE loudly (louder than talking or loud enough to be heard through closed doors)?	Yes	No
Do you often feel TIRED , fatigued, or sleepy during daytime?	Yes	No
Has anyone OBSERVED you stop breathing during your sleep?	Yes	No
Do you have or are you being treated for high blood PRESSURE ?	Yes	No

BANG		
BMI more than 35kg/m2?	Yes	No
AGE over 50 years old?	Yes	No
NECK circumference > 16 inches (40cm)?	Yes	No
GENDER : Male?	Yes	No

TOTAL SCORE		
-------------	--	--

High risk of OSA: Yes 5 - 8

Intermediate risk of OSA: Yes 3 - 4

Low risk of OSA: Yes 0 - 2

questionnaire-


[https://www.google.com/url?](https://www.google.com/url?sa=i&url=https%3A%2F%2Fgpnotebook.com%2Fsimplepage.cfm%3FID%3Dx20190721193924949909&psig=AOvVaw2ZY_RN5Q5xW0E6hGyLswat&ust=1677649078989000&source=images&cd=vfe&ved=OCBEQjhqFwoTCJi57vy_t_OCFQAAAAAAdAAAAABAb)

[sa=i&url=https%3A%2F%2Fgpnotebook.com%2Fsimplepage.cfm%3FID%3Dx20190721193924949909&psig=AOvVaw2ZY_RN5Q5xW0E6hGyLswat&ust=1677649078989000&source=images&cd=vfe&ved=OCBEQjhqFwoTCJi57vy_t_OCFQAAAAAAdAAAAABAb](https://www.google.com/url?sa=i&url=https%3A%2F%2Fgpnotebook.com%2Fsimplepage.cfm%3FID%3Dx20190721193924949909&psig=AOvVaw2ZY_RN5Q5xW0E6hGyLswat&ust=1677649078989000&source=images&cd=vfe&ved=OCBEQjhqFwoTCJi57vy_t_OCFQAAAAAAdAAAAABAb)

2.Research Methodology

Sleep apnea can be identified with the airflow data.Also I will verify the point - Sleep apnea can be identified with the surge in arousal during sleep.Which i will do by analysing the airflow data.Also I will use the psg data to identify the brain waves during the intervals of apnea.

2.0 Road map



2.1 Downloading MROS dataset

Software NSRR gem
Ruby


2.2 Airflow

Software-Matlab
Reason-Airflow is the basis of identification of Apnea.


Labels were provided in my data set although verifying it would more solidify the results.

I have data set of airflow measured at 16 hz ,over 16x60 data points in a minute ,I averaged it to get an average in a minute .512 minutes of overall recording is available.

If it is intake i.e value >0 then assigning it a label of 1 otherwise 0. So 0 is exhale or no air exchange .



airflow data during apnea



airflow data during no apnea

2.2.1 Airflow conclusion

Airflow data matches with labels during sleep apnea which confirms that labels are true and there are large gaps of no air intake during the interval.

2.2.2 Airflow data plot code

```
clear all
close all
clc

%% Load xml file

pro_xml = readstruct("mros-visit1-aa0169-profusion.xml");

%% Load data is needed
data = edfread("mros-visit1-aa0169.edf");
sampdata = cell2mat(data.Airflow);

num_blocks = floor(length(sampdata) / 16);
averaged_data = zeros(num_blocks, 1);


for i = 1:num_blocks
    block_start = (i - 1) * 16 + 1;
    block_end = i * 16;
    averaged_data(i) = mean(sampdata(block_start:block_end));
end

plot(1:num_blocks, averaged_data);
xlabel('Block number');
ylabel('Average value');
title('Averaged Data from 32000 Data Set');
```


2.3 Eye Movement

Software-Matlab

Reason-To verify whether there are awake points during the given labels of apnea



Right eye movement



Left eye movement


2.3.1 EYE movement conclusion

Airflow data matches with labels during sleep apnea which confirms that labels are true and there are large gaps of no air intake during the interval.

3.0 EEG data

From A1,A2,C3,C4 labeling the delta alpha beta gamma delta waves.I have data set of EEG at 256hz.

3.1 Stages of EEG data processing




```
clear all
close all
clc
```

```
%% Load xml file
```

```
pro_xml = readstruct("mros-visit1-aa0169-profusion.xml");
```

```
%% Load data is needed
```

```
data = edfread("mros-visit1-aa0169.edf");
```

```
% Load the EEG data
```

```
load('brain_data.mat'); % replace with your own data file name
```

```
% Define the sampling rate
```

```
Fs = 256; % Hz
```

```
delta_band = [0.5 4]; % Hz
```

```
theta_band = [4 8]; % Hz
```

```
alpha_band = [8 13]; % Hz
```

```
beta_band = [13 32]; % Hz
```

```
gamma_band = [32 100]; % Hz
```

```
A1_channel = 1; % A1
```

```
A2_channel = 2; % A2
```

```
C3_channel = 3; % C3
```

```
C4_channel = 4; % C4
```

```
delta_eeg = bandpass(eeg_data(:, A1_channel), delta_band, Fs);
```

```
theta_eeg = bandpass(eeg_data(:, A1_channel), theta_band, Fs);
```

```
alpha_eeg = bandpass(eeg_data(:, A1_channel), alpha_band, Fs);
```

```
beta_eeg = bandpass(eeg_data(:, A1_channel), beta_band, Fs);
```

```
gamma_eeg = bandpass(eeg_data(:, A1_channel), gamma_band, Fs);
```

```
% power spectral density
```

```
delta_power = bandpower(delta_eeg, Fs, delta_band);
```

```
theta_power = bandpower(theta_eeg, Fs, theta_band);
```

```
alpha_power = bandpower(alpha_eeg, Fs, alpha_band);
```

```
beta_power = bandpower(beta_eeg, Fs, beta_band);
```

```
gamma_power = bandpower(gamma_eeg, Fs, gamma_band);
```

```
% Combine the features for all channels into a single vector
```

```
features = [delta_power, theta_power, alpha_power, beta_power, gamma_power];
```

```
% Display the extracted features
```

```
disp(features);
```

3.2 EEG comparing data

1.Averaging the individual wave power in a minute

2.output-the wave having the largest averaged power density in a minute and denoting it with a sign 1.

```
num_blocks = floor(length(sampdata) / 1000);
```

```
averaged_data = zeros(num_blocks, 1);
```

```
for i = 1:num_blocks
```

```
block_start = (i - 1) * 15360 + 1;
```

```
block_end = i * 15360;
```

```
averaged_data(i) = mean(sampdata(block_start:block_end));
```

Human Brainwaves

GAMMA
32 - 100HZ



Heightened
perception, learning,
problem solving tasks,
cognitive processing

BETA
13 - 32HZ



Awake,
alert consciousness,
thinking, excitement

ALPHA
8 - 13HZ



Physically and
emotionally relaxed

THETA
4 - 8 HZ



Creativity, insight, deep
states, dreams, deep
meditation, reduced
consciousness

DELTA
0.5 - 4HZ



Deep (dreamless) sleep,
loss of bodily
awareness, repair

4.0 Results

putting everything on an excel sheet for easy viewing

	B	G	H	I	J	K	L	M	N
134	0	0	0	0	1	0	0		
135									
136	0	0	1	1	0	0			
137									
138	0	0	0	1	0	0			
139									
140	0	0	0	1	0	0			
141									
142	0	0	0	1	0	0			
143									
144	0	0	0	0	0	0			
145									
146	0	0	0	1	0	0			
147									
148	0	0	0	0	0	0			
149									
150	0	0	0	0	0	0			
151									
152	0	0	0	1	0	0			
153									
154	0	0	0	0	0	0			
155									
156	0	0	0	0	0	0			
157									
158	0	0	0	0	0	0			
159									
160	0	0	0	0	0	0			
161									
162	0	0	0	0	0	0			
163									
164	0	0	0	0	0	1			
165									
166	0	0	0	1	0	0			
167									
168	0	0	0	0	0	0			
169									

- B-airflow
- G-delta
- H-alpha
- I-beta
- J-gamma
- K-theta

4.1 Observation

from 66 minute to 110 minute -it is observed that it is an episode of apnea where airflow data signifies it by 0.

The brain waves prevalent were beta and partially deta.

beta is highest in 21 discrete minutes with 5 minutes continuously.We also see that beta was increasing in the minutes before the episode.

delta is highest in 7 discrete minutes with 2 minutes continuously.

alpha is seen in only 2-3 minutes

4.2 Observation


from 138 minute to 162 minute -it is observed that it is an episode of apnea where airflow data signifies it by 0.

The brain waves prevalent were beta and partially delta.

beta is highest in 11 discrete minutes with 4 minutes continuously. We also see that beta was increasing in the minutes before the episode.

delta is highest in 8 discrete minutes with 2 minutes continuously.

alpha is seen in only 2-3 minutes



	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q	R
277																		
278																		
279																		
280																		
281																		
282																		
283																		
284																		
285																		
286																		
287																		
288																		
289																		
290																		
291																		
292																		
293																		
294																		
295																		
296																		
297																		
298																		
299																		
300																		
301																		
302																		
303																		
304																		
305																		
306																		
307																		
308																		
309																		
310																		
311																		
312																		
313																		
314																		
315																		
316																		
317																		
318																		
319																		
320																		
321																		
322																		
323																		
324																		

5.0 Conclusion

During the episodes of apnea-airflow stops accompanying with eye movements In the brain , beta is prevalent before and during apnea , with fluctuations of delta and alpha waves. These fluctuations of delta and alpha waves are common in normal sleep , therefore the only thing to be noted was the increased beta waves.

6.0 Precautions

Through constant analysis of brain data , if we observe a surge in beta waves for more than 2 minutes it is likely an episode of apnea and the person can be woken up with help of a person or a machine to prevent it